



## *IMPROVING PROFITABILITY THROUGH FLEXIBLE SPACE SEPARATION*

Manufacturers of the Original Goff Curtain Walls  
700 Hickory Street Pewaukee, Wisconsin 53072

Phone: 800-234-0337 Fax: 262-691-3255

Email: sales@goffscw.com Web: www.goffscurtainwalls.com

### **Goff's Corner Cover Installation Instructions**

1. Hinge your Goff's Tuff-Screens together at a 90-degree angle, step to the inside of the screens. Unspool the round rubber welting, cut two pieces to the height of the vertical aluminum frame and set aside.



2. Unroll the 8' long corner cover and cut to the same height as the rubber welting. Discard the remaining corner cover material



3. Tuck the black corner cover material into the grooves on the face of the vertical aluminum frame. The material will stay in place while you prepare to Fasten the corner cover with the round rubber welting.



4. Starting at the top of the frame, press the round rubber welting on to the face of the corner cover material and into the vertical groove in the face of the aluminum frame until you have reached the bottom. (TIP: A squirt of "Windex" directly on to the rubber welting allows it to slide into the aluminum groove more easily).



5. Repeat process down the other side.

